



TH	THAILAND
----	----------


Diagram / Parts List

DSC163

CORDLESS STEEL ROD CUTTER



(TH) DSC163 / CORDLESS STEEL ROD CUTTER



TH	THAILAND
----	----------

DSC163 / CORDLESS STEEL ROD CUTTER

Item	Sub	Parts No.	Parts Description	Qty	I/C	E/C No.	Close No.	Remark
001		183C36-3	HOUSING SET	1				
	C10	263005-3	RUBBER PIN 6	2				
	D10		INC. 97					
002		620283-2	LED CIRCUIT	1				
003		266130-9	TAPPING SCREW BIND PT 3X16	9				
004		455011-4	REAR COVER	1				
005		619336-2	ROTOR	1				
006		629116-8	STATOR COMPLETE	1				
007		455005-9	MOTOR BRACKET	1				
008		256375-7	ROD 3	2				
009		253401-3	FLAT WASHER 18	1				
010		221558-8	INTERNAL SPUR GEAR 41	1				
011		226193-7	SPUR GEAR 13	5				
012		144591-2	CARRIER COMPLETE	1				
013		422168-6	RUBBER SEAL	1				
014		455006-7	GEAR CASE	1				
015		911017-7	PAN HEAD SCREW M3X12	4				
016		253888-9	FLAT WASHER 25	1				
017		961055-9	RETAINING RING S-15	1				
018		211234-2	BALL BEARING 6902LLB	1				
019		319616-3	GEAR HOUSING	1				
020		266326-2	TAPPING SCREW 4X18	4				
021		211233-4	BALL BEARING 6802LLB	1				
022		326996-0	SPINDLE	1				
023		650710-5	SWITCH C3JW-4B	1				
024		643874-2	TERMINAL	1				
025		451162-1	LOCK LEVER	1			DL032	
025-1		413R94-8	LOCK LEVER	1	O	DL032		
026		457799-2	COVER	1				
027		142263-3	INDICATOR PANEL COMPLETE	1				
029		SC03501140	ECCENTRIC SHAFT	1				
030		SC07512110	BOLT HB5X50	4				
031		SC07610030	SPRING WASHER 5	4			Y07942	
031-1		942101-7	SPRING WASHER 5	4	O	Y07942		
032		SC03222700	FLANGE SET PLATE	1				
033		SC04007620	LEAF SPRING	2				
034		SC04007430	POSITION SPRING	2				
035		SC07900010	STEEL BALL S4	2				
036		SC03221200	INTERMEDIATE HOUSING	1				
037		SC03251180	FLANGE	1				
038		SC00000068	FLAT WASHER 4	4				
039		SC07511060	BOLT HB4X22	4				
040		SC00000050	BALL BEARING 6002RU	1				
041		SC06504000	OIL SEAL MHS15257	1			Y07942	
041-1		SC00000484	OIL SEAL MSH15257	1	X	Y07942		
042		SC00000061	HEX. BOLT 10X15	1				
043		SC00000489	SEAL WASHER	1				
044		SC03212300	BEARING HOUSING	1				
045		SC04601440	LINER B	1				
046		SC03500390	PISTON	3			Y09419	
047		SC04003020	PISTON RETURN SPRING	3				
048		SC03500460	CHECK VALVE	3			Y07942	
048-1		SC00000149	CHECK VALVE	3	X	Y07942		
049		SC00000021	CHECK VALVE SPRING	3			Y07942	
049-1		SC00000468	SPRING #43449N2	3	X	Y07942	Y07966	
049-2		SC04002000	CHECK VALVE SPRING	3	<	Y07966		
050		SC03500540	METAL PACKING	3				
051		SC06505590	O RING S-8	3				
052		SC00000487	STOP RING H19	1				
053		SC00000465	NEEDLE BEARING HOLDER A T45421	1				
054		SC00000466	NEEDLE BEARING #RNAF81510	1				
055		SC00000467	NEEDLE BEARING HOLDER B T45422	1				
056		SC07100030	BALL BEARING 625	1				
057		SC00000020	MAGNET	2				
058		SC06505300	O RING S4	1				

A:

Interchange
O : Yes
X : No
< : the new part can be substituted for the current.
> : the current part can be substituted for the new.
S : Interchangeable as a set.

